



#### Data sheet

## **KNX IP Interface 731**

(Art. # 5242)

Compact bus powered interface between LAN/Ethernet and KNX bus






Photo of the device

# **Application area**

The KNX IP Interface 731 is a compact interface used to connect a PC to the KNX network. The connection is made through LAN (IP). Power is supplied via the KNX bus.

The IP address can be obtained by a DHCP server or by manual configuration (ETS) respectively. This device works according to the KNXnet/IP specification using the core, the device management and the tunneling part.

The buttons are for diagnostic purposes. The LEDs indicate the operating status and communication errors on the bus.

### **Technical Specification**

### Electrical safety

- Protection (acc. EN 60529): IP 20
- Bus safety extra low voltage SELV DC 29 V

### CE marking according to

- Low voltage directive 2014 / 35 / EU
- EMC directive 2014 / 30 / EU
- RoHS directive 2011 / 65 / EU
- EN 50491-3: 2009, EN 50491-5-1: 2010
  EN 50491-5-2: 2010, EN 50491-5-3: 2010
- EN 61000-6-2: 2005
  EN 61000-6-3: 2007 + A1: 2011
- EN 50581: 2012

### Environmental requirements

- Ambient temp. operating: 5 ... + 45 °C
- Ambient temp. non-op.: 25 ... + 70 °C
- Rel. humidity (non-condensing): 5 % ... 93 %

#### Mechanical data

- Housing: plastic (PC)
- DIN rail mounted device, width: 1 unit (18 mm)
- Weight: approx. 40 g

#### Controls and indicators

- 2 buttons and 3 LEDs, multicolor
- KNX programming button with LED (RD)

#### Ethernet

- 10BaseT (10Mbit/s)
- Supported internet protocols ARP, ICMP, IGMP, UDP/IP, DHCP and Auto IP
- Up to 5 KNXnet/IP Tunneling connections simultaneously

### KNX

Medium TP

## Power Supply

KNX Bus approx.15 mA

#### Connectors

- Bus connector for KNX (RD / BK)
- LAN RJ-45 socket

### Installation Instructions

 The device may be used for permanent interior installations in dry locations, within distribution boards or small casings with DIN rail.



### WARNING

- The device may be built into distribution boards (230/400V).
- The device must be mounted and commissioned by an authorized electrician.
- The prevailing safety rules must be heeded.
- The device must not be opened.
- For planning and construction of electric installations, the relevant guidelines, regulations and standards of the respective country are to be considered.



Weinzierl Engineering GmbH

D-84508 Burgkirchen / Alz Germany http://www.weinzierl.de info@weinzierl.de